

無線網路多媒體系統

Wireless Multimedia System

Radio Propagation: Issues & Models

中央大學 吳曉光博士

<http://wmlab.csie.ncu.edu.tw/course/wms>

We
provide
無線網路多媒體實驗室
Wireless
Wireless Network & Multimedia Laboratory
Solution

Lecture II Agenda

- ◆ Radio Propagation
 - Physical of radio propagation
 - Two types of propagation models
 - Outdoor vs. Indoor Radio Propagation Model
 - How to do simple “link budget” calculation
 - Combating the radio channel impairment
- ◆ Wireless Modem Design
- ◆ Modern Application: 911 services



Reading list for This Lecture

◆ Required Reading:

(Jorgen95) J. B. Andersen, T. S. Rappaport, “Propagation Measurements and Models for Wireless Communications channels”, (IEEE Communication Magazine), pp. 42~49

(Jeffrey H98) Jeffrey H. Reed, Kevin J. Krizman, Brian D. Woerner, and T. S. Rappaport, “An Overview of the Challenges and Progress in Meeting the E-911 Requirement for Location Service, (IEEE Communication Magazine), pp.30~37


Further Reading

(Rappaport97) T. S. Rappaport, K. Blankenship, H. Xu, “Propagation and Radio System Design Issues in Mobile Radio Systems for the GloMo Project



The mystery of the Radio Propagation




How to deal with Radio Propagation




Where are you from?



QoS and Multimedia Traffic Support



Simplified View of a Digital Radio Link



Digital to Analog Modulation




Figure 6.2 Single-stage digital modulation (TDMA and FDMA).

Digital-Digital-Analog Modulation




Figure 6.3 Two stages of modulation in a spread spectrum system.

Digital Correlator





Figure 6.4 Two stages of demodulation in a spread spectrum receiver.


Multiple correlators

- ◆ Multiple correlators in each receiver
- ◆ At any instant of time, the signal carriers in the different correlators are synchronize to signal paths with different propagation times
- ◆ A search circuit examines the arriving signal in order to detect the appearance of a new path, then assign a correlator to synchronize the signal on the path




Key role for the radio propagation

- ◆ Radio Propagation determines
 - the area which could be covered
 - The maximum data rate in a system
 - Battery power requirement for mobile transceivers



Radio Channel

- ◆ Free Space
- ◆ Land Mobile
- ◆ Multi-path Propagation
- ◆ Shadow



Some Distributions


- ◆ Normal (Gaussian)
- ◆ Log-normal Distribution
- ◆ Rayleigh Distribution
- ◆ Rician Distribution
 - Dominant path
- ◆ Impulse Response



Propagation Mechanisms in Space with Objects

- ◆ Reflection (with Transmittance and Absorption)
 - Radio wave impinges on an object
 - Surface of earth, walls, buildings, atmospheric layers
 - If perfect (lossless) dielectric object, then zero absorption
 - If perfect conductor, then 100% reflection
- ◆ Diffraction
 - Radio path is obstructed by an impenetrable surface with sharp irregularities (edges)
 - Secondary waves “bend” around the obstacle (Huygen’s principle)
 - Explain how RF energy can travel without LOS
 - “shadowing
- ◆ Scattering (diffusion)
 - Similar principles as diffraction, energy reradiated in many directions


Reflection, Diffraction, and Scattering in Real-Life



- ◆ Received signal often a sum of contributions from different directions
- ◆ Random phases make the sum behave as noise (Rayleigh Fading)

Small-scale and Large-scale Fading

- ◆ Signal fades rapidly as receiver moves, but the local average signal changes much more slowly




Analysis of the Propagation

◆ Large Scale Effect

- The variation of the mean received signal strength over large distance or long time intervals

◆ Small Scale Effect

- The fluctuations of the received signal strength about a local mean, where these fluctuations occur over small distances or short time interval



Large Scale -> Link Budget



Free Space Propagation Model

- ◆ Used when Transmitter and Receiver have a clear, unobstructed, line of sight (LOS) path
 - e.g. satellite channels, microwave LOS radio links

- ◆ Free space power at a receiver antenna at a distance d from transmitter antenna is

$$P_r(d) = \frac{P_t G_t G_r \lambda^2}{(4\pi)^2 d^2 L}$$

where,

G_t and G_r are antenna gains


$L \geq 1$ is the system loss factor not related to propagation
(e.g. loss due to filter losses, hardware)

- ◆ Path loss = signal attenuation as a positive quantity in dB

$$Pl(dB) = 10 \log \frac{P_t}{P_r}$$

$$P_t(dBm) = 10 \log [P_t(mW) / 1mW]$$

Example: Ground Reflection (2-Ray) Model



- ◆ Model found a good predictor for large-scale signal strength over distances of several kilometers for mobile systems with tall towers (heights > 50m) as well as for LOS microcell channels
- ◆ Can show (physics) that for large d

$$P_r(d) = \frac{P_t G_t G_r h_t^2 h_r^2}{d^4}$$

- ◆ Much more rapid path loss than expected due to free spaces

Log-Distance Path Loss Model

- ◆ Assume average power (in dB) decreases proportional to log of distance

$$\overline{PL}(d) = \overline{PL}(d_0) + 10n \log\left(\frac{d}{d_0}\right)$$

- ◆ Justification?
 - Measurements
 - Intuition/theory.. Recall; free space, ground-reflection model
- ◆ Problem: “Environment Clutter” may differ at two locations at the same time (Log-normal Shadowing)

$$\overline{PL}(d) = \overline{PL}(d_0) + 10n \log\left(\frac{d}{d_0}\right) + X_\sigma$$

Typical Path Loss Exponent, n

Environment	Path Loss Exponent, n
Free Space	2
Urban area cellular / PCS	2.7 to 4.0
Shadow urban cellular / PCS	3 to 5
In building line of sight	1.6 to 1.8
Obstructed in building	4 to 6
Obstructed in factories	2 to 3

Practical Link Budget Design Using Path Loss Models

- ◆ Bit-Error-rate is a function of SNR (signal-to-noise ratio), or equivalently CIR (carrier-to-interference ratio), at the receiver
 - The “function” itself depends on the modulation scheme
- ◆ Link budget calculations allow one to compute SCR or CIR
- ◆ Battery Life → Talk Time → received/Transmitted power → Path Loss Models



$$SNR(dB) = P_s(dBm) - N(dBm)$$

$$P_s(dBm) = (P_t) + (G_t) + (G_r) - (\overline{PL}(d))$$

$$N = KT_0BF$$

$$N = -174(dBm) + 10\log_{10} B + F(dB)$$

Example Link Budget Calculation

- ◆ Maximum separation distance vs. transmitted power (with fixed BW)
 - Given
 - ◆ Cellular phone with 0.6W transmitted power
 - ◆ Unity gain antenna, 900 MHz carrier frequency
 - ◆ SNR must be at least 25 dB for proper reception
 - ◆ Receiver BW is $B=30\text{KHz}$, noise figure $F=10\text{ dB}$
 - What will be the maximum distance?
 - Solution:
 - ◆ $N = -174\text{ dBm} + 10 \log 30000 + 10\text{ dBm}$
 - ◆ For $\text{SNR} > 25\text{ dB}$, we must have $P_r > (-119+25) = -94\text{ dBm}$
 - ◆ $P_t = 0.6\text{W} = 27.78\text{ dBm}$
 - ◆ This allows path loss $PL(d) = P_t - P_r < 122\text{ dB}$
 for free space, $n=2$, $d < 33.5\text{ km}$
 for shadowed urban with $n=4$, $d < 5.8\text{ km}$

Small Scale -> Quality of Service




Small-Scale Fading Effects (over small t and x)

- ◆ Fading manifests itself in three ways
 - Time dispersion caused by different delays limits transmission rates
 - Rapid changes in signal strength over small x or t
 - Random frequency modulation due to varying Doppler shifts
- ◆ In urban areas, mobile antenna heights \ll height of buildings
 - Usually no LOS from base station
- ◆ Moving surrounding objects also cause time-varying fading

Factors Influencing Small-Scale Fading

- ◆ Multi-path propagation
- ◆ Speed of Mobile
- ◆ Speed of surrounding objects
- ◆ Transmission bandwidth of the signal

Delay Spread



Parameters of a Multipath Channel

- ◆ Multipath Channel Impulse Response (measured by sounding technique)

$$h(t) = \sum_{i=1}^N a_i e^{j\phi_i} \delta(t - \tau_i)$$

- ◆ Four important parameters of interest

- RMS delay spread

$$\sigma_\tau = \sqrt{\overline{\tau^2} - (\bar{\tau})^2}, \bar{\tau} = \sum_k a_k^2 \tau_k / \sum_k a_k^2, \overline{\tau^2} = \sum_k a_k^2 \tau_k^2 / \sum_k a_k^2$$

- Coherence bandwidth

$$B_c = \frac{1}{5\sigma_\tau}$$

- Doppler spread

$$B_D = f_m = \max((v / \lambda) \cos \theta) = (v / c) f_{carrier}$$

- Coherence time

$$T_c = 0.423 / f_m$$

Types of Fading

- ◆ Two independent mechanisms:
 - Time Dispersion (Due to Multi-path delays)
 - ◆ Flat fading
 - ◆ Frequency Selective Fading
 - Doppler Spread (due to Motion of mobile or channel)
 - ◆ Fast Fading
 - ◆ Slow Fading

Fades: Why do we care?

- ◆ Data Rate
- ◆ Equalization
- ◆ Fades result in “Error Bursts”
- ◆ Average duration of (Flat) fades
- ◆ Depends primarily on speed of the mobile.

The Design of Wireless Modem




Combating Errors


- ◆ Increase transmitted power
- ◆ (Adaptive) Equalization
- ◆ Antenna or space diversity for “Multipath”
- ◆ Forward error correction
- ◆ Automatic Repeat Request (ARQ)

Direct Sequence Spread Spectrum


To transmit a 0 the station use a unique “chip sequence”:



To transmit a 1 the station use the one’s complement of its chip sequence:




Therefore if data is 1010 it will transmit:



Frequency Hopping Spread Spectrum

- ◆ Transmitted signal is spread over a wide range of frequencies. (i.e. 2.400-2.485 GHz)
- ◆ Transmission usually hop 35 times per second.



Antenna Types



- *Omni Directional Antenna*



- ◆ YAGI Directional Antenna

Modern Applications: 911 Service




Location Service

E-911 Requirement for Location Service

- ◆ 1996, FCC (Federal Communications Commission) announced its mandate for enhanced emergency services for cellular phone callers.
- ◆ The current deadline for this capability is October 1, 2001






GPS Nominal Constellation

24 Satellites in 6 Orbital Planes

4 Satellites in each Plane

20,200 km Altitudes, 55 Degree Inclination




Global Positioning System (GPS) Master Control and Monitor Station Network

GPS (cont.)

◆ Position location

- 3-D 座標 (x,y,z) 需要3個獨立方程式可解.
- 三個GPS衛星得到三個距離量度，可設定所需的三個方程式.
- 需要第四個衛星來求得另一距離量度以建立第四個方程式 (T_{error})
- 這樣就可定位出他的位置
- With accuracy of approximately 100 m.



The Global Positioning System

Measurements of code-phase arrival times from at least four satellites are used to estimate four quantities: position in three dimensions (X, Y, Z) and GPS time (T).

Introduction

- ◆ Safety is the primary motivation for vehicle position location.
- ◆ Landline telephone companies to provide 911 emergency service .
- ◆ 1994, begin investigating similar service for U.S cellular and PCS providers.
- ◆ E-911 service include caller's ANI and street address information.

Mobile Location Solution

Driving Force :

Legal aspects :

- Fire brigades, hospitals and other emergency centers.

Commercial aspects :

- Differentiation : new and attractive services.
- Reduced costs : operators can adapt their network to match calling patterns.
- Increased revenues : commercial services that use positioning information is infinite.


Positioning mechanism and requirement

Terminal-based :


- Positioning intelligence is stored in the terminal or its SIM card.
- Network-assisted global positioning system (A-GPS).

Network-based :


- Positioning intelligence isn't built into the handset.
- Measurement of Cell global identity and timing advance (CGI+TA) 、 uplink time of arrival (UL-TOA).



Mobile location solution has been designed to handle a variety of positioning methods and application interfaces.



Network-assisted GPS (A-GPS) is a positioning product with very attractive characteristics.



UL-TOA and E-OTD methods each use the triangulation of time difference between base stations and the terminal to determine positions.

Location applications

Information services :

- Location-based yellow pages, events, and attractions (ex. What is happening today in town near here?) .

Tracing services :

- Tracing of a stolen car, helping paramedics to locate persons quickly in an emergency situation, and giving a towing service or automobile repair shop the location of a motorist in need (out of gas, flat tire, dead battery).


Location applications (cont.)

Resource management :

- Taxi fleet management, the administration of container goods, and the assignment and grouping of railway repairmen.

Navigation :

- Vehicle or pedestrian navigation.



The chest of drawers illustrates how different applications can be grouped strategically for use by their beneficiaries.

Channel Propagation and Fading




Figure 4. Received power as a function of distance: in a street (left), in a pavilion (right); BER and handover (right).